



DWG. NO. NA5-A129RC
 MODEL ASGALRC L.H. CONTROL LABELER
 INFED CAN TRACK ASSEMBLY

MODEL ASGALRC L.H. CONTROL LABELER INFEED CAN TRACK ASSEMBLY
 DWG. NO. NA5-A129RC

ITEM NO.	PART NO.	DESCRIPTION
1	NL5-1234	CAN FEED TRACK FILLER
2	NL5-129	FLEXIBLE CAN FEED TRACK
3	NAL-153	INFEED PLATE SUPPORT
4	NL5-160	SPACER SPRING SUPPORT ROD
5	NLE-156L	SPACER SPRING SUPPORT
6	NL5-A157	SPACER SPRING ASSEMBLY
7	NA5-155F	SHAFT SUPPORT - F.E.
8	NLE-129/A	FLEXIBLE CAN FEED TRACK
9	NLE-A157L	SPACER SPRING ASSEMBLY
10	NL5-154L	INFEED SUPPORT TIE ROD
11	NLE-1034	STOP ROD GUIDE
12	NL5-154S	INFEED SUPPORT TIE ROD
13	NLE-1035	CONTAINER STOP ROD
14	FP-JN06C	PLATED JAM NUT
15	FP-JN12F	PLATED JAM NUT
16	NA-PFC1	FLOW CONTROL VALVE
17	NLE-1033	STOP ROD CYLINDER MOUNT
18	NL5-3010	SWITCH MOUNT PLATE
19	NLE-1036	STOP ROD SUPPORT
20	NA-PC1	AIR CYLINDER 1-1/8 X 4
21	NA-PV15	AIR LIMIT VALVE - LR4
22	NA-PVTE3	PULSE TIMER ELEMENT
23	NA-PVEB1	1-ELEMENT BASE ASSEMBLY
24	NAL-1932	CAN TRACK SUPPORT BLOCK - F.E.
25	NL5-193L	INFEED CAN TRACK SUPPORT ROD
26	FP-SC06	SET COLLAR
27	NL5-1232	CAN TRACK RETAINER
28	NL5-193S	INFEED CAN TRACK SUPPORT ROD
29	NLE-1232	CAN TRACK RETAINER - F.E.
30	NA-ESW25	LIMIT SWITCH ARM
31	FP-SQ05C28	PLATED SQUARE HEAD SET SCREW
32	NL5-1235	INFEED TRACK SUPPORT BRACKET
33	NL5-119	COLUMN TIE ROD
34	NA5-16	FEED END PLATE
35	NAL-1931	GUM POT RACK SUPPORT
36	NL5-323/2	CAN TRACK SUPPORT PLATE
37	NL5-323/1	CAN TRACK SUPPORT BAR
38	NL5-323	CAN TRACK SUPPORT ARM
39	NL5-A195F	INFEED CAN TRACK ASSY. (INCLUDES ITEM #29)
40	NL5-1233	CAN TRACK SHIM
41	NL5-439	HANDLE DEFLECTOR
42	NL-1275L	GUM POT ADJUSTMENT SCALE
43	NL5-118	GUM POT ADJUSTMENT RACK

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 DR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com