



FORM "C"  
BRASS



FORM "D"  
RUBBER



DWG. NO. NA5-A31RC  
MODEL ASGALRC L.H. CONTROL LABELER  
GUM POT ASSEMBLY

DWG. NO. NA5-A31RC

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-3181	GUM POT LID STUD
2	NLE-319A	GUM POT LID
3	NL5-389R	GUM ROLL SHAFT SUPPORT-1/4"
4	NLE-321	GUM POT LID HANDLE
5	NL5-391	THERMOMETER MOUNT BLOCK
6	NLE-320	GUM POT THERMOMETER
7	NLE-A31/P	GUM POT BASE (INCLUDES ITEM #15)
8	NA-PF14	1/2" NPT BRASS PIPE PLUG
9	NL5-385	GUM POT STUD MOUNT
10	FP-SQ06C28	SQUARE HEAD SET SCREW
11	NL5-383A	BACK GUM ROLL SCRAPER
12	NL5-384	BACK GUM ROLL GUIDE
13	NL5-390	BACK GUM ROLL SCRAPER FILLER
14	NL5-382A	BACK GUM ROLL SCRAPER SUPPORT
15	NLE-340	BRONZE BUAHING
16	NLE-A338	FEED ROLL ASEMBLY (INCLUDES ITEM #15 & #31)
17	NL5-336	BOTTOM GUM ROLL SCRAPER
18	NL-4325	EXTENSION SPRING
19	NLE-324	ROCKER ARM SPRING STUD
20	NL5-389L	GUM ROLL SHAFT SUPPORT-1/2"
21	NL5-A334	TOP GUM ROLL SHAFT ASSEMBLY(INCLUDES ITEM #24)
22	NL5-388	ROCKER ARM TIE PLATE
23	NL5-386	ROCKER ARM PIVOT
24	F-SP5/32-24	SPRING PIN
25	NL5-387	ROCKER ARM SIDE SUPPORT
26	NL5-335	TOP GUM ROLL SCRAPER
27	NLE-3207B	RUBBER GUM ROLL DISC - FORM D
28	NLE-A356B	CENTER GUM ROLL ASSEMBLY - FORM D
29	NLE-333E	BRASS GUM ROLL DISC - FORM C
30	NLE-A333B	CENTER GUM ROLL ASSEMBLY - FORM C
31	NLE-339	FEED ROLL SHAFT
32	NLE-38	FEED ROLL SHAFT SPUR GEAR
33	F-WK07	WOODRUFF KEY

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.  
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.  
P.O. BOX 467 210 BLETTNER AVENUE  
HANOVER, PA. 17331

TEL. (717) 637-2133 OR 637-8998  
FAX. (717) 637-2966 WEB SITE: [www.labeler.com](http://www.labeler.com)