



DWG. NO. NAL-A21SCFRC  
 MODEL A5RC. L.H. CONTROL LABELER  
 CONTINUOUS FEED (FLIGHT BAR TYPE)  
 LABEL FEED DRIVE ASSEMBLY

MODEL A5RC L.H. CONTROL LABELER  
CONTINUOUS FEED (FLIGHT BAR TYPE) LABEL FEED DRIVE ASSEMBLY  
DWG. NO. NAL-A21SCFRC

ITEM NO.	PART NO.	DESCRIPTION
1	NAL-2901	LABEL FEED SUPPORT PLATE
2	NAL-2904	LABEL FEED SUPPORT SPACER
3	NLE-B122012	BEARING
4	NLEBIR081212	INNER RACE
5	NLE-AC229	CONTROL LABEL FEED GEAR ASSEMBLY
6	NLE-BB1416/8	BRONZE BUSHING
7	FP-SC14	SET COLLAR
8	NLE-2102	MANUAL CONTROL GEAR
9	NLE-A243RHS	LABEL FEED RACK SUPPORT ASSY. (INCLUDES ITEM #10)
10	NLE-2251	BRONZE BUSHING
11	NAL-2903	LABEL FEED SUPPORT BRACE
12	FP-SC12	SET COLLAR
13	NLE-2100	LABEL FEED ADJUST SHAFT
14	NLE-AC2148	HAND WHEEL ASSEMBLY (INCLUDES ITEM #15)
15	NL-4102A	STEEL CRANK HANDLE
16	F-SH08F36	SOCKET HEAD CAP SCREW
17	NLE-243LHS	LABEL FEED RACK SUPPORT
18	NLE-C2152	BRONZE BUSHING
19	NLE-C222A	LABEL FEED CLUTCH MEMBER
20	NLE-AC226A	FEED SHAFT SUPP. BKT. ASSY. (INCLUDES ITEM #18-#48)
21	NLE-C235	LABEL FEED CLUTCH ROLLER
22	NLE-C2125	CLUTCH ROLLER STUD
23	NLE-C223	LABEL FEED CLUTCH MEMBER
24	NLE-C2146	BRONZE BUSHING
25	NLE-AC2145	CLUTCH LEVER SUPPORT ASSY. (INCLUDES ITEM #24)
26	NLE-C2126	CLUTCH SUPPORT STUD
27	NLE-C2127	LABEL FEED CLUTCH COLLAR
28	NLE-639	CLUTCH LEVER SUPPORT SHAFT
29	NAL-215SCF	CONTINUOUS LABEL FEED CONTROL SHAFT
30	NAL-2909	REAR LABEL FEED DRIVE SHAFT
31	NLE-C2122	LABEL FEED CLUTCH MEMBER
32	NLE-C2123A	LABEL FEED CLUTCH MEMBER
33	NLE-C219A	LABEL FEED ADJUSTMENT DRIVEN GEAR
34	NLE-C221A	LABEL FEED ADJUSTMENT GEAR
35	NLE-C229/2	MANUAL CONTROL GEAR
36	NLE-C231A	LABEL FEED GEAR SUPPORT
37	NAL-2905	LABEL FEED SUPPORT SPACER
38	NAL-2902	LABEL FEED SUPPORT PLATE
39	NLE-C244	LABEL FEED DRIVE SPROCKET
40	NLE-C2130	REAR LABEL FEED SHAFT SCREW
41	NAL-234	SHAFT SUPPORT BUSHING
42	NAL-2908	LABEL FEED DRIVE SPROCKET
43	NAL-2919	LABEL FEED SHAFT SUPPORT
44	NAL-2907	CONTINUOUS LABEL FEED TUBE
45	NLE-AC230A	LABEL FEED GEAR SUPPORT ASSY. (INCLUDES ITEM #10)

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.  
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.  
P.O. BOX 467 210 BLETNER AVENUE  
HANDOVER, PA. 17331  
TEL. (717) 637-2133 OR 637-8998  
FAX. (717) 637-2966 WEB SITE: [www.labeler.com](http://www.labeler.com)

SEPTEMBER 26, 2002

MODEL ASRC L.H. CONTROL LABELER  
CONTINUOUS FEED (FLIGHT BAR TYPE) LABEL FEED DRIVE ASSEMBLY  
DWG. NO. NAL-A21SCFRC

ITEM NO.	PART NO.	DESCRIPTION
46	NLE-C2128	WASHER
47	NLE-C2143	LABEL FEED CLUTCH KEY
48	NLE-C234A	SHAFT SUPPORT BRACKET BUSHING
49	NLE-C228A	LABEL FEED GEAR SPACER
50	F-SH04C32	SOCKET HEAD CAP SCREW
51	NL-47L	EXTENSION SPRING
52	NAL-2906	CLUTCH LEVER RETAINER
53	NLE-C2138	CLUTCH LEVER RETAINER BAR
54	NLE-C227	LABEL FEED CLUTCH LEVER
55	NLE-A237SU	OUTSIDE LABEL SUPPORT ASSEMBLY
56	NLE-A236SCF	CENTER LABEL PLATE SUPP. ASSY.(INCLUDES ITEM #57-#60-#64)
57	NL-240A	LABEL SUPPORT EXPANSION SPRING
58	NCLF-838/1	LABEL PLATE NO. 1 - 1/2"
	NCLF-838/2	LABEL PLATE NO. 2 - 1"
	NCLF-838/3	LABEL PLATE NO. 3 - 1-1/2"
	NCLF-838/4	LABEL PLATE NO. 4 - 2"
	NCLF-A838/5	LABEL PLATE NO. 5 ASSY. - 3" (INCLUDES ITEM #59)
	NCLF-A838/6	LABEL PLATE NO. 6 ASSY. - 4" (INCLUDES ITEM #59)
	NCLF-A838/7	LABEL PLATE NO. 7 ASSY. - 5" (INCLUDES ITEM #59)
59	NLE-2252	LABEL PLATE SUPPORT PIN
60	NLE-239CF	CARRIER ROD
61	NLE-206	LABEL BED SUPPORT
62	NLE-2103/A	LABEL FEED RACK
63	NLE-W207	LABEL PLATE ADJ. SCREW WELDMENT
64	NLE-255/1	SPRING STUD
65	NL-47S	EXTENSION SPRING
66	NLE-1032	TRIP VALVE ARM EXTENSION
67	NLE-1038	TRIP VALVE
68	NLE-1031	TRIP VALVE MOUNT PLATE
69	NA-229	SWITCH TRIP BAR
70	NA-230	TRIP BAR SPACER
71	F-SH06C16	SOCKET HEAD CAP SCREW

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.  
AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.  
P.O. BOX 467 210 BLETTNER AVENUE  
HANOVER, PA. 17331  
TEL. (717) 637-2133 OR 637-8998  
FAX. (717) 637-2966 WEB SITE: [www.labeler.com](http://www.labeler.com)

PAGE 2 OF 2