



DWG. NO. NLE-A216RC
 MODEL E5RC/E7RC/EPRC
 L.H. CONTROL LABELER
 ABEL FEED DRIVE ASSEMBLY

MODEL E5RC/E7RC/EPRC L.H. CONTROL LABELER LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NLE-A216RC

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-266A	FEED CONTROL LEVER
2	NLE-2106	FEED CONTROL ROD CONNECTOR
3	NLE-262B	LABEL FEED CONTROL ROD
4	NLE-W2301	TRIP ROD GUIDE
5	NLE-A265C	LABEL FEED CONTROL ROD ASSEMBLY
6	NLE-A279RC	ECCENTRIC BUSHING HOUSING ASSEMBLY
7	FP-JN08F/LH	PLATED JAM NUT - LEFT HAND
8	NL-1641	GREASE FITTING - SHORT
9	NLE-280	ECCENTRIC BUSHING WASHER
10	FP-JN08F	PLATED JAM NUT
11	NLE-281	ECCENTRIC CONNECTING ROD
12	NLE-A250L	RATCHET PAWL ASSY. - L.H.
13	NLE-282	CONNECTING ROD CONNECTOR
14	NLE-271	FEED CONTROL PIN HOUSING
15	NLE-2278A	COMPRESSION SPRING
16	NLE-A272	FEED CONTROL PAWL ASSY.
17	NLE-269	DETENSION PAWL SPRING STUD
18	NLE-255	BELL CRANK SPRING STUD
19	FP-SQ05C08	PLATED SQUARE HEAD SET SCREW
20	NLE-267	DETENSION PAWL STUD
21	NL-328H	EXTENSION SPRING
22	NL-289L	EXTENSION SPRING
23	NLE-A250R	RATCHET PAWL ASSY. - R.H.
24	NLE-254	BELL CRANK BUSHING
25	NLE-W253SRC	CONTROL DISC CRANK (SHORT FRAME)
	NLE-W253LRC	CONTROL DISC CRANK (LONG FRAME)
26	NLE-252	BELL CRANK FILLER
27	NLE-256	CONNECTING ROD ROCKER ARM PIN
28	NLE-249	RATCHET PAWL STUD
29	NLE-251	CONNECTING ROD ROCKER ARM
30	FP-SC14	SET COLLAR
31	NLE-246	RATCHET WHEEL
32	NLE-A247A	PAWL CONTROL DISC ASSY. (INCLUDES ITEM #26, & #33)
33	NLE-248	CONTROL DISC SPACER
34	NL-27	HANDWHEEL
35	FP-SC06	SET COLLAR
36	NLE-2295	RELEASE ROD - R.C.

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com