



DWG. NO. NLE-A21SCF
 MODEL E5 LABELER
 CONTINUOUS FEED (FLIGHT BAR TYPE)
 LABEL FEED DRIVE ASSEMBLY

MODEL E5 LABELER CONTINUOUS FEED (FLIGHT BAR TYPE) LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NLE-A21SCF

ITEM NO.	PART NO.	DESCRIPTION
1	NLE-2113	BRONZE BUSHING
2	NLE-A224A	LABEL BED RISER SUPPORT ASSY. (INCLUDES ITEM #1-#9)
3	NLE-AC226A	FEED SHAFT SUPPORT BRACKET ASSY. (INCLUDES ITEM #18-#37)
4	F-SH08F36	SOCKET HEAD CAP SCREW
5	NLE-243L	LABEL FEED RACK SUPPORT
6	NLE-B122012	BEARING
7	NLEBIR081212	INNER RACE
8	NLE-AC229	CONTROL LABEL FEED GEAR ASSY.
9	NFT-286	BRONZE BUSHING
10	NLE-C217SA	CONTINUOUS LABEL FEED CONTROL SHAFT
11	NLE-A243R	LABEL FEED RACK SUPPORT ASSY. (INCLUDES ITEM #13)
12	NLE-2102	MANUAL CONTROL GEAR
13	NLE-2251	BRONZE BUSHING
14	NLE-C228A	LABEL FEED GEAR SPACER
15	NLE-2100	LABEL FEED ADJUST SHAFT
16	NLE-AC2148	HAND WHEEL ASSY. (INCLUDES ITEM #17)
17	NL-4102A	STEEL CRANK HANDLE
18	NLE-C2152	BRONZE BUSHING
19	NLE-C2123A	LABEL FEED CLUTCH MEMBER-F.E.
20	NLE-C2122	LABEL FEED CLUTCH MEMBER - F.E.
21	FP-SC12	SET COLLAR
22	NLE-C2126	CLUTCH SUPPORT STUD
23	NLE-AC2145	CLUTCH LEVER SUPPORT ASSY. (INCLUDES ITEM #24)
24	NLE-C2146	BRONZE BUSHING
25	NLE-C242S	CLUTCH LEVER SUPPORT
26	NLE-C223	LABEL FEED CLUTCH MEMBER - D.E.
27	NLE-C222A	LABEL FEED CLUTCH MEMBER - D.E.
28	NLE-C218SA	REAR LABEL FEED DRIVE SHAFT
29	NLE-A225A	LABEL BED RISER SUPPORT ASSY. (INCLUDES ITEM #1-#13)
30	NLE-C219A	LABEL FEED ADJUSTMENT DRIVEN GEAR
31	NLE-C231A	LABEL FEED GEAR SUPPORT
32	NLE-C244	LABEL FEED DRIVE SPROCKET
33	NLE-C2130	REAR LABEL FEED SHAFT SCREW
34	NLE-C216A	LABEL FEED DRIVE SHAFT
35	NLE-AC230A	LABEL FEED GEAR SUPPORT ASSY. (INCLUDES ITEM #13)
36	NLE-C221A	LABEL FEED ADJUSTMENT GEAR
37	NLE-C234A	SHAFT SUPPORT BRACKET BUSHING
38	NLE-C2143	LABEL FEED CLUTCH KEY
39	NLE-C2128	WASHER
40	NLE-C220A	CONTINUOUS LABEL FEED TUBE
41	NLE-C2137S	CLUTCH LEVER RETAINER
42	NLE-C235	LABEL FEED CLUTCH ROLLER
43	NLE-C2125	CLUTCH ROLLER STUD
44	NLE-C2127	LABEL FEED CLUTCH COLLAR
45	NLE-C2139S	CLUTCH LEVER TENSION ROD

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETTNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com

MODEL E5 LABELER CONTINUOUS FEED (FLIGHT BAR TYPE) LABEL FEED DRIVE ASSEMBLY
 DWG. NO. NLE-A21SCF

ITEM NO.	PART NO.	DESCRIPTION
46	NC-77	COMPRESSION SPRING
47	NLE-C227	LABEL FEED CLUTCH LEVER
48	NLE-C2138	CLUTCH LEVER RETAINER BAR
49	NLE-A237SU	OUTSIDE LABEL SUPPORT ASSEMBLY
50	NLE-A236SCF	CENTER LABEL PLATE SUPP. ASSY. (INCLUDES ITEM #51-#54-#55)
51	NL-240A	LABEL SUPPORT EXPANSION SPRING
52	NCLF-838/1	LABEL PLATE NO. 1 - 1/2"
	NCLF-838/2	LABEL PLATE NO. 2 - 1"
	NCLF-838/3	LABEL PLATE NO. 3 - 1-1/2"
	NCLF-838/4	LABEL PLATE NO. 4 - 2"
	NCLF-A838/5	LABEL PLATE NO. 5 ASSY. - 3" (INCLUDES ITEM #53)
	NCLF-A838/6	LABEL PLATE NO. 6 ASSY. - 4" (INCLUDES ITEM #53)
	NCLF-A838/7	LABEL PLATE NO. 7 ASSY. - 5" (INCLUDES ITEM #53)
53	NLE-2252	LABEL PLATE SUPPORT PIN
54	NLE-239CF	CARRIER ROD
55	NLE-255/1	SPRING STUD
56	NL-47S	EXTENSION SPRING
57	NLE-206	LABEL BED SUPPORT
58	NLE-2103/A	LABEL FEED RACK
59	NLE-W207	LABEL PLATE ADJ. SCREW WELDMENT
60	NLE-2101S	LABEL BED FILLER (ALUMINUM FRAME ONLY)
61	NLE-C2132	LABEL FEED TAKE UP SPROCKET
62	NLE-C2133	TAKE UP SPROCKET BUSHING
63	NLE-C2136	TAKE UP SPROCKET WASHER
64	NLE-C2134	TAKE UP SPROCKET STUD
65	NLE-C2161	LABEL FEED DRIVE CHAIN
66	NLE-1032	TRIP VALVE ARM EXTENSION
67	NLE-1038	TRIP VALVE
68	NLE-1031	TRIP VALVE MOUNT PLATE
69	NA-229	SWITCH TRIP BAR
70	NA-230	TRIP BAR SPACER
71	F-SH06C16	SOCKET HEAD CAP SCREW

WHEN ORDERING REPAIR PARTS, GIVE MODEL NO., MACHINE NO. & SERIAL NO.
 AS WELL AS PART NUMBER AND NAME.

NEW WAY PACKAGING MACHINERY, INC.
 P.O. BOX 467 210 BLETNER AVENUE
 HANOVER, PA. 17331
 TEL. (717) 637-2133 OR 637-8998
 FAX. (717) 637-2966 WEB SITE: www.labeler.com